

Extensions for Size C Bilco Basement Doors

(To increase the length when required to fit a longer stairwell)

ASSEMBLY INSTRUCTIONS

1. First assemble the size C Bilco Door in accordance with the instruction pamphlet in the Door package.
2. The extension assembly consists of three parts: left side panel, right side panel, and cover panel. With the wider part of the bevelled flange on each side panel toward the top, as shown, fasten these to the back angle of the Bilco Door side pieces with the 1/4 " x 1/2 " bolts and nuts provided.
3. Install cover panel so *flanges overlap* the side panels and the header flange of the Bilco Door. Secure this with 1/4 " x 1/2 " bolts, with nuts on inside.
4. Follow Basement Door instructions for installation of extension header against masonry building or to fit it properly under the shingles or clapboards on a frame building.
5. Using holes provided at bottom of each side panel, fasten extension to concrete using the slotted hex-head screws as described in Basement Door instructions.
(note: 24" & 30" sides panels have two holes, 12" & 18" side panels have one hole and 6" side panels have no holes as concrete anchorage is not required).
6. When caulking around the exterior of the Bilco Door and extension be sure to caulk where side pieces join extension, both sides.

Extension Size	Shipping Weight
6"	26 lbs.
12"	41 lbs.
18"	58 lbs.
24"	73 lbs.
* 30"	91 lbs.

* 30" Extension available to O.E.M. only

Hardware Supplied with Extension	
13	1/4" x 1/2" round head bolts
13	1/4" nuts
8	#12 slotted hex head screws
8	plastic shields
4	spring nuts

